



TECHNICAL DATA SHEET

STONE REPLACEMENT OF THE TUCSON

TOOLS REQUIRED:

7/16" Wrench

Procedure:

1. Remove the top *stones* by reaching under the back of the top casting and pushing the stones upward with one hand and removing them with your other hand.
2. Loosen the two 1/4-20 nuts which attach the top of the stove to the sides and bottom.
3. Lift the stone clip/heat shield upwards. Once the stone clip moves up, pull it towards the back of the stove. The stone clip will slide between the casting and the back shroud.
4. Carefully remove the side stones through the side of the stove. The top stone needs to be lifted high enough to remove the bottom stone first.
5. Replace the side stones by inserting the top stone through the side of the stove. Hold the top stone up so that the bottom stone can be put in place. Lower the top stone onto the bottom stone.
6. Once the side stones are in place, slide the stone clip in place between the stones and the tie rods. The stone clip should be centered on the top and bottom stone.
7. Tighten the 1/4-20 nuts on the top of tie rods to place tension on the tie rods and to secure the stones in place.
8. Gently set the top stones back in place on the top of the stove.