

## Technical Data Sheet

### Tribute DV 8050 Stone Installation Instructions

*Part #9050-41 (Soapstone) \**

**Publish Date: 05/31/2006**

#### **INCLUDED IN KIT:**

3-Top Stones: 6-3/8" x 13-1/8"

4-Side Stones: 7-3/4" x 10-3/4"

**STEEL (shipped with stove):**

2-Side stone clips/heat shields  
(used to retain the side stones)

\* Follow these instructions for all Stone Kits:

9050-63 Aztec Green Marble

9050-53 Autumn Brown Granite

9050-51 Dakota Red Granite

9055-43 Platinum Pearl

9050-56 Misty Mauve Granite (no longer available)

9050-55 Orion Black Granite (no longer available)

#### **PROCEDURE:**

 **Note: Always work on a cold stove. Use care in handling stones and enamel front to avoid chipping and scratching of parts.**

1. Identify and lay out stones based on description above.
2. Remove cast top from stove by carefully lifting up, taking care not to chip the edges.
3. Slide side stones (**7-3/4" x 10-3/4"**) down through slots in top with polished side facing out. To avoid scratching and make sliding easier, ensure you keep the stones back from the corner braces as you slide them down. Install only one stone at a time. Do not use one stone to push the other down (See figure 1).



**Figure 1- Inserting the Side Stones**



4. Replace the top casting on the stove.
5. Lay top stones into place starting from one side to the other.