

Technical Data Sheet

Sterling-Ht 8532 Stone Set Installation Instructions

Kit Number: 95-57346 (Polished Soapstone)*

Publish Date: 5/12/2009

KIT COMPONENTS:

3-Top Stones:
(2 Left/Right Stones 6-3/8" x 10-1/16")
(1 Top Center Stone 12" x 12")
4-Front Stones: (Corner Stones 3-1/2" x 9-1/2")
4-Side Stones: (Side Stones 8" x 9")


TOOLS REQUIRED:

None

STEEL (shipped on stove):

2-Side stone clips/heat shields – used to retain the side stones.

PROCEDURE:

 **Note:** Always work on a cold stove. Use care in handling stones and enamel front to avoid chipping and scratching of parts.

1. Identify and lay out the stones based on component description above.
2. Remove cast front from stove by carefully lifting and then pulling bottom toward you. Take care not to drag the front on ash lip.
3. Slide right and left hand side stones (8" x 9") down through slots in top with polished side facing out. Ensure you keep the stone back from the corner braces as you slide it down to avoid scratching, and to make sliding easier. Completely install only one stone at a time. Do not use one stone to push the other (See figure 1).



Figure 1 – Inserting the Side and Front Stones

4. With the polished surface facing out and beveled edge facing the corner brace, place the front stones (3-1/2" x 9-1/2") into position left and right of viewing glass. Bottom stones fit into a pocket cast into the base and must be vertical before placing any upper front stones. (See figure 1)
5. Lay the top stones carefully into place starting from one side to the other.
6. Re-install the front casting on the stove. Insert the lip on the top of the front into the retaining slots under the top casting before carefully setting the bottom edge of the front into place.

***Follow these instructions for all Sterling-Ht Stone Sets:**

Kit Number	Description
95-57351	Dakota Red Granite
95-57353	Autumn Brown Granite
95-57355	Orion Black Granite
95-57356	Misty Mauve Granite
95-57363	Aztec Green Marble
95-57364	Misty Gray Marble