

Technical Data Sheet

Installing the Sterling- Ht DV Model 8532 Accessory Spark Screen

Kit Number 95-69320

Date: 8/19/2004

MATERIALS REQUIRED:

Screen

TOOLS REQUIRED:

None

PROCEDURE:

- 1) Lift the façade up and pull it out at the bottom to remove it from the front of the stove.



Photo 1
Front façade removed
from stove.



Photo 2
Sterling Spark Screen

- 2) Turn the façade over and hang the screen on the slots as shown in photo number 3.



Photo 3

Screen hung on inside of the façade. Hooks hang on lower portion of grill slots.

- 3) Place the façade back onto the stove. Slip the top of façade under the upper portion of the top casting and allow the bottom of the façade to drop into place.



Photo 4

Screen and façade installed onto the stove.