

# Technical Data Sheet

## Green Mountain 40 - 8640 Baffle Replacement

*Kit #96-76400*

### **INCLUDED IN KIT:**

2ea. 3070-020: Ceramic Baffles

### **TOOLS REQUIRED:**

Safety Glasses  
Work Gloves

**BEFORE YOU BEGIN:** Check to make sure you have all the components listed in the kit. Read the instructions all the way through. Always work on a cool stove.

### **PROCEDURE:**

1. Remove the metal baffle protector by sliding it to the left or right, and then rotating it towards you.
2. Lift up on the right side baffle and gently pull the left side baffle down and out of the stove.
3. Remove the right side baffle.
4. Set the new right side baffle in place with the notched edge positioned toward the center of the firebox.
5. While gently lifting up on the notched side of the right side baffle, position the new left side baffle in the stove so that the notched edges overlap and can lay snugly together.
6. Lower the now mated baffles into their final position and reinstall the metal baffle protector as it was removed in step 1.

