




# Craftsbury

## Model 8391

### Illustrated Parts List

Production Dates: April 2013 -  
Serial #: 00700 -





## Replacement Kits

Key	Part #	Description
37	<b>93-73900</b>	<b>Front Door Latch Kit</b>
	4500-2975	Set Screw
	4700-0790	Door Latch Spacers
	5010-081	Crank Handle
	5021-032	Flat Washer
	5240-0138	Latch Spring
	5390-051	Door Latch
38	<b>93-71910</b>	<b>Front Door Handle Kit</b>
	3900-177	Wooden Handle
	4500-1682	Round Head Screw 1/4-20x3-3/4"
	4600-0400	Lock Washers
	5391-085	Handle Extension
39	<b>93-71915</b>	<b>Ash Door Handle Kit</b>
	3900-177	Wooden Handle
	4500-1359	Pan Head Screw 1/4-20x3/4"
	4500-1680	Round Head Screw 1/4-20x3-1/4"
	4600-0300	Flat Washer
	4600-0400	Lock Washers
	4700-0850	Spacer
	5240-147	Disc Spring
	5391-021	Ash door handle lever
40	<b>93-71918</b>	<b>Ash Door Latch Kit</b>
	4300-0000	Roll Pins
	4500-1876	Pan Head Screw 1/4-20x1/2"
	4500-4680	Flat Head Screws M6x10mm
	5240-154	Latch Spring
	5391-031	Ash Pan Door Latch
41	<b>93-58905</b>	<b>Door Glass Kit</b>
	3030-047	Door Glass
	3110-053	3/16" Gasket Rope, Low Density
	5021-060	Glass Clips
	3120-021	Glass Clip Gaskets
	4500-4603	Flat Head Screws M4x10mm
	<b>93-58900</b>	<b>Gasket Kit</b>
	3110-051	1/2" Gasket Rope, Low Density
	3110-053	3/16" Gasket Rope, Low Density
	3120-021	Glass Clip Gaskets
99-090N	Gasket Glue	