



Technical Data Sheet

Shelburne 8370 and Shelburne 8371

Replacement of the Top Casting

Part #2310-755*

Date: 6/30/2004

Page: 1 of 1

CONTENTS:

#2310-745 - Stove Top Casting

TOOLS REQUIRED:

7/16" Wrench
7/16" Socket w/ Extension

REQUIRE ITEMS:

1/2" Rope Gasket (9ft)
Gasket Adhesive

BEFORE YOU BEGIN: Work on a cool stove.

PROCEDURE:

1. Locate the two bolts on the back of the top casting which are accessible from outside the stove. Remove these bolts with a 7/16" wrench or socket. To remove the front two bolts, you will need to open the front door and reach through the stainless steel throat baffle in the front of the firebox with a socket and extension. Remove these bolts.
2. The top casting can now be taken off the stove. Turn it upside down and remove the four screws that hold the stainless steel heat shield to the top. Remove the shield and line it up on the new and secure it to the top with the four screws.
3. Apply a small amount of gasket glue to the channel in the new top casting. Pack the fresh 1/2" gasket into this channel, making sure there are no gaps and the two ends of the gasket meet. Trim off any excess gasket.
4. Place the new top onto the firebox body. Secure the front bolts with the socket and extension. Insert the bolts into the tabs in the back of the top casting and tighten with the wrench or socket.

* **2510-755** refers to the matte top casting. Order the enamel top castings by the desired color.

(802) 888-5232

317 Stafford Ave. Morrisville, VT 05661
[Http://www.hearthstonestoves.com](http://www.hearthstonestoves.com)

(802) 888-7249